

INTERNAL BONDING
P323

- | <u>NO.</u> | <u>DESCRIPTION</u> |
|------------|--------------------|
| 1. | Stemhead Fitting |
| 2. | Main Shroud Tangs |
| 3. | Thru-Hull |
| 4. | Backstay Tang </td |
| 5. | Engine |
| 6. | Fuel Tank |
| 7. | V-Drive |
| 8. | Deck Fill |
| 9. | Strut |
| 10. | Internal Ballast |

