

PEARSON 323
THRU-HULL LOCATION SCHEMATIC

PORT SIDE

STARBOARD SIDE

NO. DESCRIPTION

- 1 ANCHOR WELL DRAIN (STB'D SIDE)
- 2 SUMP PUMP DISCHARGE (STB'D SIDE) SHOWER
- 3 ENGINE RAW WATER INTAKE (PORT)
- 4 OPT. GALLEY SEAWATER INTAKE (PORT)
- 5 COCKPIT SCUPPERS (P&S)
- 6 DECK SCUPPERS (P&S)
- 7 LIFTING SLING
- 8 VANITY SINK DISCHARGE (STB'D)
- 9 GALLEY SINK DISCHARGE INTO PORT COCKPIT SCUPPER
- 10 ELECTRIC BILGE PUMP DISCHARGE (PORT TRANSOM)
- 11 HEAD INTAKE (STB'D)
- 12 HEAD OVERBOARD DISCHARGE (STB'D SIDE)

